

How to Install Your Vehicle Monitoring Module

Find Your Vehicle's OBD Connector Port

It's usually on or under the dash, on the driver's side. Other possible locations are the center console area or inside the glove compartment.

Need help finding your vehicles OBD port?

- Use the OBD Locator in the app to see a picture of where the OBD port is in your vehicle. After logging in for the first time, click the button labeled OBD LOCATOR. If needed, you can access the locator from the web site and from the app. On the website, click on your Username in the upper right hand corner. From the drop down menu, click the button labeled OBD LOCATOR. In the mobile app, this function is located in Menu > Settings.
 - NOTE: The Delphi Connect app will remain logged in indefinitely, unless the user logs out using the MENU and Log Out selection.
 - NOTE: The Delphi Connect app will be updated periodically and you will receive notification of updates via standard Android and iOS app update notifications.

Install Your Module

Use your U.S. Cellular[®] smartphone to check that you have a strong signal where your vehicle is parked.

- Make sure your vehicle is parked outside in a safe location and the engine is turned off.
- Now plug the module into the OBD port (or into the extension cable if it is required). **Make sure that the module is fully seated.**
- Wait for the Status LED to turn solid blue.

For helpful installation Tips – See delphiconnect.com/install

Initiate Module Setup

Stop!

Do not proceed until the Status LED is solid blue, indicating activation on the U.S. Cellular[®] network.

- Insert your vehicle's ignition key and turn it to the on position (not ACC/Accessory). **Do not start the engine!**
 - Typically, all of the warning lamps on the dashboard will illuminate briefly in this position
 - For pushbutton-start vehicles, the procedure is typically to push the start button without your foot on the brake (check your vehicle owner's manual to determine how many presses are required to turn the ignition on).

- Press and hold the Function Button on the side of the Vehicle Monitoring Module until the Status LED blinks red one time. This will occur after approximately 5 seconds. Then release the Function Button. The LED will blink red while vehicle setup occurs.
- Wait up to 30 seconds for the LED to display a mix of solid and blinking green.
- Wait an additional 10 seconds for the LED to go out.
- When the LED begins to flash blue every 10 seconds, setup is complete.

Stop! Your vehicle may not be compatible with the Vehicle Monitoring system (check the fitment guide at delphiconnect.com/fitment) or you did not place the ignition in the On position. Do not proceed if the Status LED never turned green but instead returned to solid blue.

NOTE: The first time the Vehicle Monitoring connects to the U.S. Cellular® network, it will perform a one-time network setup which will take several minutes.

Note: To avoid any unnecessary drain on the vehicle battery. It recommended not to leave the Vehicle Monitoring Module in the solid blue state for more than 24 hours.

Verify Module Setup

- Start the engine and let it run for at least 30 seconds.
- Stop the engine and wait at least 20 seconds.

You are now ready to access your vehicle information using the Delphi Connect app.