

# U.S. Cellular<sup>®</sup> Home Phone Making Calls and Voicemail

## Making Calls

1. Before making a call, make sure that the wireless signal is strong.
2. Lift the handset of your telephone and enter the telephone number to make a call.
3. When your call is finished, hang up the telephone or return the telephone to its base to ensure that you can receive calls.



### NOTE:

When first using this device, please dial \*228 to enable it.

## Receiving Calls

When the telephone rings, lift the handset or press **Hands-Free** if available on the handset to answer the incoming call.

## Three-Way Calling

While on an existing call, dial the second phone number directly then press **Flash** key. When the second party answers, press the **Flash** key again to complete the three-way connection. If the second party does not answer, press the **Flash** key twice to end the connection and return to the first party.

Note: If your phone does not have a **Flash** key, use the off-hook mechanism supported by your phone instead.

## Voicemail

The voicemail indicator (📞) will blink green when you have new voicemail messages.

1. Lift the handset of your telephone.
2. Dial **1** or **\*86** and wait about 4 seconds to access your voicemail.
3. Follow the system prompts to listen to and manage your voicemails.