

U.S. Cellular[®] Home Phone **Setting the Device Volume**

Adjusting Volume

During a call, continuously press * or # for 1 second to enter the volume adjusting mode, and then press * to decrease volume or press # to increase volume. Pressing other keys or doing nothing for 5 seconds will exit this mode.

Four volume levels are available (level 1 to level 4), and the default level is 2.

NOTE:

The device and an external phone usually work together. This method only changes the volume of the device (the volume of the whole system will be changed at the same time), and you can also change the volume of the external phone (if supported).