


GET TO KNOW THE Samsung Galaxy S[®] 4

SIM Card

The SIM card in the Samsung Galaxy S 4 is essential to the phone's operation. Without it, you cannot make phone calls or use any data or messaging services on the U.S. Cellular network. Once the SIM has been inserted, do not remove it from the phone.



1. The SIM slot is located under the battery cover on the back of the phone. To remove the battery cover, insert your fingernail or a slim object into the slot on the top left side of the phone. Gently pry the back from the phone.



2. Locate the SIM slot. Please note that the SIM card should not be inserted into the microSD™ card slot, which is next to the SIM card slot. If in doubt, look for the word SIM and a small diagram of the SIM card etched on or next to the slot.



3. With the gold contacts facing down, notched end first, gently slide the SIM card into the slot.



4. Re-align the battery cover with the back of the phone and press around the edges of the cover until it snaps into place.