


U.S. Cellular® Home Phone Troubleshooting


Troubleshooting

1. Check the power adapter to ensure it is properly connected, check the battery to ensure it has been installed in the device correctly, and check the device is powered on.

Power Button



2. Make sure your home telephone equipment has power and is connected properly to the U.S. Cellular® Home Phone.



3. Check that the Signal Indicator light is illuminated. If not, make sure the “On/Off” button on the back of the device is “On” (press and hold until the Signal Indicator light illuminates).
4. Move the device to an area with sufficient network signal (Green or Yellow Signal Indicator light).

